

1. Fondale carry bag.



2. Take out the parts of the frame from the bag.



3. Insert the screw to the base of the foot.



4. Connect the foot and end pole. Turn the foot clockwise to fasten.




5. Repeat the instruction to the other end pole. Make sure both poles are secured.



6. Connect the top and bottom poles.



7. Twist the top and bottom bar to extend or adjust the poles.



8. Insert the top and bottom poles into the graphic.



9. Attach the bottom and end poles by using the Fondale end knobs. Turn the knob clockwise to fasten.



10. Repeat the previous instruction to attach the top pole.



11. Adjust the graphic.



12. Adjust the poles according to the size and height of the graphic.

