



BT-Tenda-10, 15, 20


Instructions




1. Assemble the tent in the area where you want to place it. Have 2 people stand on both sides, hold the 2 outer legs, lift off the ground and gently pull until the frame is extended.



2. Grab the bottom part of the peak truss (shown) on each sides, slowly lift and step backwards to fully open the tent. BE CAREFUL not to get your finger stuck. (For 10x20 tent see 3).



3. For 10x 20 Tent, stand in front of the middle outer leg and grab the bottom part of the peak truss (shown), slowly lift and step backwards until the tent is fully open. BE CAREFUL not to get your finger stuck.




4. Pull the auto slider with one hand, while holding down the top leg with the other hand until the snap button locks into place. Repeat on all corners.




5. Adjust the height of the tent by pulling out the leg extension until the snap button clicks into place. Repeat on the other side. Adjustment holes are allocated at the bottom part of the legs, so you can modify the height of the Tent.



1. Lift two legs and press the snap button to release. Push the legs extension in, to go back to the original height. Repeat on the other side.



2. Press the snap button to release the auto slider, then push down. Repeat on all corners.



3. On each side, grab the top portion of the peak truss (shown), slowly lift and shake to fold the canopy in place, walk forward until it's 3/4 closed. Hold the 2 outer legs and completely close the tent. BE CAREFUL not to get your finger stuck.

TO TAKE DOWN THE CANOPY

IMPORTANT

- WINDY CONDITIONS: Use stake kit or weight bag set.
- HEAVY WINDS: Make sure to take the canopy down.
- WET CANOPY: Make sure it's dry before storing.
- CLEANING: Use mild detergent and water.
- RAIN: Do not leave canopy unattended.

